

Codice Code	Alimentazione Input Alimentation	Uscita Output Sortie	Corrente Current Courant	Potenza VA Power VA Puissance VA
IT.0546.ME01	220V	0-220V	2,4A	900VA
IT.0546.ME02	220V	0-260V	1,3A	600VA
IT.0546.ME03	380V	0-380V	0,9A	600VA
IT.0546.ME04	380V	0-380V	2A	1320VA
IT.0546.ME05	380V	0-420V	1,5A	1050VA
IT.0546.ME06	380V	0-450V	1A	780VA
IT.0546.ME07	400V	0-400V	2A	1350VA
IT.0546.ME08	400V	0-430V	1,5A	1140VA
IT.0546.ME09	400V	0-450V	1A	780VA

Codice Code	Alimentazione Input Alimentation	Uscita Output Sortie	Corrente Current Courant	Potenza VA Power VA Puissance VA
IT.0547.ME01	220V	0-220V	5,6A	2100VA
IT.0547.ME02	220V	0-260V	2A	900VA
IT.0547.ME03	220V	0-280V	1,8A	900VA
IT.0547.ME04	380V	0-380V	2,2A	1500VA
IT.0547.ME05	380V	0-380V	4A	2700VA
IT.0547.ME06	380V	0-420V	3A	2160VA
IT.0547.ME07	380V	0-450V	2,5A	1950VA
IT.0547.ME08	380V	0-480V	2A	1680VA
IT.0547.ME09	400V	0-400V	3,6	2500VA
IT.0547.ME10	400V	0-450V	3A	2350VA
IT.0547.ME11	400V	0-480V	2A	1680VA

Codice Code	Alimentazione Input Alimentation	Uscita Output Sortie	Corrente Current Courant	Potenza VA Power VA Puissance VA
IT.0548.ME01	220V	0-220V	9A	3300VA
IT.0548.ME02	220V	0-260V	4A	1800VA
IT.0548.ME03	220V	0-280V	3,7A	1800VA
IT.0548.ME04	380V	0-380V	4A	2700VA
IT.0548.ME05	380V	0-380V	9A	5900VA
IT.0548.ME06	380V	0-420V	5A	3600VA
IT.0548.ME07	380V	0-450V	5A	3900VA
IT.0548.ME08	380V	0-480V	4A	3300VA
IT.0548.ME09	400V	0-400V	9A	6000VA
IT.0548.ME10	400V	0-450V	5A	3900VA
IT.0548.ME11	400V	0-480V	4A	3300VA

Codice Code	Alimentazione Input Alimentation	Uscita Output Sortie	Corrente Current Courant	Potenza VA Power VA Puissance VA
IT.0549.ME01	220V	0-220V	19A	7200VA
IT.0549.ME02	220V	0-260V	13A	6000VA
IT.0549.ME03	220V	0-280V	12,5A	6000VA
IT.0549.ME04	380V	0-380V	10A	6600VA
IT.0549.ME05	380V	0-380V	15A	9900VA
IT.0549.ME06	380V	0-420V	7,5A	5400VA
IT.0549.ME07	380V	0-420V	10A	7200VA
IT.0549.ME08	380V	0-450V	7A	5400VA
IT.0549.ME09	380V	0-480V	6,5A	5400VA
IT.0549.ME10	400V	0-400V	14A	9600VA
IT.0549.ME11	400V	0-450V	10A	7800VA
IT.0549.ME12	400V	0-480V	7,5A	6300VA

Codice Code	Alimentazione Input Alimentation	Uscita Output Sortie	Corrente Current Courant	Potenza VA Power VA Puissance VA
IT.0550.ME01	220V	0-220V	32A	12000VA
IT.0550.ME02	220V	0-280V	22A	10500VA
IT.0550.ME03	380V	0-380V	18A	12000VA
IT.0550.ME04	380V	0-380V	25A	16500VA
IT.0550.ME05	380V	0-450V	13,5A	10500VA
IT.0550.ME06	380V	0-480V	12,5A	10500VA
IT.0550.ME07	400V	0-400V	20A	13800VA
IT.0550.ME08	400V	0-400V	25A	17000VA
IT.0550.ME09	400V	0-450V	13,5A	10500VA
IT.0550.ME10	400V	0-480V	12,5A	10500VA

Codice Code	Alimentazione Input Alimentation	Uscita Output Sortie	Corrente Current Courant	Potenza VA Power VA Puissance VA
IT.0551.ME01	220V	0-220V	44A	16500VA
IT.0551.ME02	220V	0-280V	37A	18000VA
IT.0551.ME03	380V	0-380V	32A	21000VA
IT.0551.ME04	380V	0-380V	36A	24000VA
IT.0551.ME05	380V	0-450V	23A	18000VA
IT.0551.ME06	380V	0-480V	21A	18000VA
IT.0551.ME07	400V	0-400V	32A	22000VA
IT.0551.ME08	400V	0-450V	23A	18000VA
IT.0551.ME09	400V	0-480V	23A	19500VA